

AIRBUS A330 JarDesign Checklist

BEFORE START

CALL GPU, FUEL TANK and STAIRS

- Wait while GPU EXT-B and GPU EXT-A AVAIL
- BAT1 and BAT2 OFF
- Wait while BAT1 and BAT2 ON
- APU BAT ON
- GPU EXT B ON
- INT LT - STBY COMPASS ON
- INT LT - CTL ON
- INT LT - DOME ON

ENTER FUEL

REMOVE FUEL TANK

- APU MASTER SW ON
- APU START ON
- PROVE / WINDOWS HEAT ON
- APU BLEED ON
- SIGNS - SEAT BELLS ON
- SIGNS - NO SMOKING ON
- SIGNS - EMER LT ARM
- COCKPIT NORMAL
- CABIN NORMAL
- TURN ADIRS IR1 TO NAV MODE
- TURN ADIRS IR2 TO NAV MODE
- TURN ADIRS IR3 TO NAV MODE
- FUEL PUMP ENG1 L1 ON
- FUEL PUMP ENG1 L2 ON
- FUEL PUMP ENG2 R2 ON
- FUEL PUMP ENG2 R1 ON

- RADIO ON
- WEATHER RADAR ON (turn to left)
- FLOOD LT (Left)
- INTEG LT
- FLOOD LT (Right)
- LT CEILING ON (BOTH SIDE)
- MAP ON (BOTH SIDE)
- CONSOLE ON (BOTH SIDE)
- FOOT WARMER ON (BOTH SIDE)

ENTER DATA TO MCDU

- Set ALTITUDE to Cruise Level (autopilot)

PUSHBACK AND START

REMOVE ALL GROUND EQUIPMENT

CLOSE ALL DOORS

- EXT LT - BEACON ON
- EXT LT - STROBE ON
- EXT LT - WING ON
- EXT LT - NAV & LOGO ON
- EXT LT - TAXI ON

CALL PUSHBACK

- PARK BRK OFF
- ENG START IGN
- START ENG2

PUSHBACK THE AIRCRAFT

- START ENG1
- PARK BRK ON

TEST JOYSTICK AND RUDDER

TAXI

TAXI THRU RUNWAY

BEFORE TAKEOFF

- PARK BRK ON
- FLAPS 1
- SPOILER ARM
- ENG START NORMAL
- ATC ON
- TCAS TA/RA
- AUTO BRK MAX ON
- BRK FAN ON
- APU MASTER SW (*no light*)
- APU START (*no light*)
- APU BLEED (*no light*)
- PACK 1 and PACK 2 OFF
- EXT LT - RWY TAKEOFF ON
- EXT LT - LAND ON
- EXT LT - NOSE TAXI ON

TAKEOFF

- PARK BRK OFF
- START CHRONO
- Thrust thru TAKEOFF

- Overhead Panel / - Pedestal Panel / - Main Instrument Panel / - Primary Flight Display
 - Navigation Display

AIRBUS A330 JarDesign Checklist

AFTER TAKEOFF

- ✂ - GEAR UP (positive climb)
- ⊖ - "LVR CLB FLASHING" ► Thrust (-) until THR CLB
- ✂ - AP1 ON (autopilot)
- ☒ - PACK 1 and PACK 2 ON
- ⌋ - FLAPS 0
- ⊖ - "BARO QNH FLASHING" ► ✂ - BARO STD
- ☒ - EXT LT - RWY TAKEOFF OFF
- ☒ - EXT LT - NOSE TAXI OFF
- ⊖ - 11,000 FEET ► ☒ - EXT LT - LAND ON
- ⊖ - "ALT CRZ (sound)" ► ☒ - SIGNS - SEAT BELLS OFF
► ☒ - SIGNS - NO SMOKING OFF
- ⊕ - 15 NM TOD ► **GET ILS ALTITUDE**
- ☒ - SIGNS - SEAT BELLS ON
- ☒ - SIGNS - NO SMOKING ON

DESCENT

- ✂ - Set **ALTITUDE to ILS ALTITUDE** (autopilot)
- ⊕ - 1 NM TOD ► ✂ - PRESS ALTITUDE (autopilot)
- ⊖ - "MORE DRAG" ► ⌋ - SPOILER FULL
- ⊖ - 11,000 FEET ► ☒ - EXT LT - LAND ON
- ⊖ - "BARO QNH FLASHING" ► ✂ - BARO QNH

APPROACH AND LANDING

- ⌋ - CONFIRM APPROACH PHASE (MCDU)
- ☒ - EXT LT - RWY TAKEOFF ON
- ☒ - EXT LT - NOSE TAXI ON
- ✂ - LS ON (autopilot)
- ⊖ - 210 TAS ► ✂ - APPR ON
- ✂ - AUTO BRK MED ON
- ✂ - BRK FAN ON
- ⌋ - FLAPS 1
- ⊖ - 180 TAS ► ⌋ - FLAPS 2
- ⊖ - 160 TAS ► ⌋ - FLAPS FULL
- ✂ - GEAR DOWN
- "RETARD SOUND" ► Thrust down

AFTER LANDING

- ⌋ - SPOILER DISARM
- ⌋ - WEATHER RADAR OFF (turn to right)
- ⌋ - WINDSHEAR OFF
- ⌋ - FLAPS 0
- ☒ - APU MASTER SW ON
- ☒ - APU START ON
- ☒ - APU BLEED ON

PARKING

- ⌋ - PARK BRK ON
- ⌋ - ENG1 OFF
- ⌋ - ENG2 OFF
- ☒ - SIGNS - SEAT BELLS OFF
- ☒ - SIGNS - NO SMOKING OFF
- ☒ - SIGNS - EMER LT OFF
- ☒ - EXT LT - BEACON OFF
- ☒ - EXT LT - STROBE OFF
- ☒ - EXT LT - WING OFF
- ☒ - EXT LT - NAV & LOGO OFF
- ☒ - EXT LT - TAXI OFF
- ☒ - EXT LT - RWY TAKEOFF OFF
- ☒ - EXT LT - LAND OFF
- ☒ - EXT LT - NOSE TAXI OFF
- ☒ - FUEL PUMP ENG1 L1 OFF
- ☒ - FUEL PUMP ENG1 L2 OFF
- ☒ - FUEL PUMP ENG2 R2 OFF
- ☒ - FUEL PUMP ENG2 R1 OFF

SECURE AIRCRAFT

- ☒ - TURN ADIRS IR1 OFF
- ☒ - TURN ADIRS IR2 OFF
- ☒ - TURN ADIRS IR3 OFF
- ☒ - APU BLEED OFF
- ☒ - APU MASTER SW OFF
- ☒ - APU BAT OFF
- ☒ - BAT1 and BAT2 OFF

☒ - Overhead Panel / ⌋ - Pedestal Panel / ✂ - Main Instrument Panel / ⊖ - Primary Flight Display
⊕ - Navigation Display