

POWER ON	
BAT 1 & 2	OFF then AUTO
APU BAT	OFF then AUTO
<b>If External Power (GPU) available</b>	
EXT PWR A OR/AND B	ON
APU : FIRE TEST	PUSH
LIGHTS : NAV & LOGO	ON
APU : MASTER SW	ON
APU : START	ON
APU BLEED	ON
EXT PWR A & B	OFF
GPU	DISCONNECTED
<b>If External Power (GPU) not available</b>	
APU : FIRE TEST	PUSH
LIGHTS : NAV & LOGO	ON
APU : MASTER SW	ON
APU : START	ON
APU BLEED	ON

COCKPIT PREPARATION	
FLOOD LT	ADJUST
INTEG LT	ADJUST
ADR 1, 3 & 2	NAV
SIGNS : NO SMOKING	ON
SIGNS : EMER EXIT LT	ON then ARM
FUEL L1, L2, R1 & R2	ON
ENG FIRE TEST	PUSH
ATIS	OBTAIN
ATC CLEARANCE	OBTAIN
ATC	SET TRANSPONDER CODE
ATC	AUTO
FMGS : A/C STATUS	CHECK
FMGS : INIT A	COMPLETE
FMGS : INIT B	COMPLETE
FMGS : F-PLN	COMPLETE
FMGS : RAD NAV	COMPLETE
FMGS : PERF	COMPLETE
EFIS OPTION	CSTR SELECTED
EFIS SCALE	ADJUST

BEFORE START	
LIGHTS : BEACON	ON
SIGNS : SEAT BELTS	ON
DOORS	CLOSED
PARK BRAKE	ON

PUSHBACK (IF REQUIRED)	
A/SKID & N/W STRG	OFF
PARK BRAKE	OFF
PUSHBACK SEQUENCE	
AFTER PUSHBACK	PARK BRAKE : ON
A/SKID & N/W STRG	ON

ENGINE START	
ENG START	IGN START
ENG MASTER 1	ON
ENG 1 START SEQUENCE	MONITOR
ENG 1 PARAMETERS	CHECK
ENG MASTER 2	ON
ENG 2 START SEQUENCE	MONITOR
ENG 2 PARAMETERS	CHECK
ENG START	NORM

AFTER START	
GND SPOILERS	ARMED
FLAPS	SET FOR TAKE-OFF
ATC	AUTO
APU BLEED	OFF
APU MASTER SW	OFF
ANTI ICE ENG1 & 2	IF REQUIRED
ANTI ICE WING	IF REQUIRED
FLIGHT CONTROLS	CHECK FREE

BEFORE TAXI	
LIGHTS : RWY TURN OFF	ON
LIGHTS : NOSE	TAXI
PARK BRAKE	OFF

LINE UP	
WEATHER RADAR	ON
WINDSHEAR	AUTO
ENG START	NORM or IGN
TCAS	TA/RA
AUTO / BRK	MAX
BRK FAN	OFF
TEST T.O CONFIG	PUSH
LIGHTS : STROBE	ON
LIGHTS : LAND	ON
LIGHTS : NOSE	T.O
PACKS 1 & 2	OFF IF REQUIRED

TAKE-OFF	
BRAKES	RELEASE
THRUST LEVERS <i>Place hands on thrust levers until V1</i>	FLEX/TOGA
CHRONO	START
AT 100 KT	"CHECKED"
AT V1	"V1"
AT VR	"ROTATION"
<b>WHEN V/S POSITIVE</b>	
LANDING GEAR	UP
LIGHTS : RWY TURN	OFF
LIGHTS : NOSE	OFF
GND SPOILERS	DISARMED
ENG START	NORM or IGN
<b>AT THRUST REDUCTION ALT</b>	
THRUST LEVERS	LEVERS CLB
IF PACKS WERE OFF FOR TAKE-OFF	PACK 1 : ON
<b>AT ACCELERATION ALT</b>	
CLB or CLB/OP	SET
<b>ABOVE "F" SPEED</b>	
FLAPS 1	SET
<b>ABOVE "S" SPEED</b>	
FLAPS 0	SET
IF PACKS WERE OFF FOR TAKE-OFF	PACK2 : ON
<b>WHEN CLEARED TO FL ABOVE TRANS ALT</b>	
BARO	SET STD

PASSING 10000 FT	
LIGHTS : LAND	OFF
SIGNS : SEAT BELTS	AS REQUIRED

BEFORE DESCENT	
FMGS : PERF > APP PHASE	COMPLETE (QNH, T°, WIND...)
AUTO / BRK	LO or MED

DESCENT	
ANTI ICE	AS REQUIRED
SPEED BRAKE	AS REQUIRED
WHEN CLEARED TO ALTITUDE	BARO : SET QNH

PASSING 10000 FT	
LIGHTS : LAND	ON
SIGNS : SEAT BELTS	ON
ILS (LS)	AS REQUIRED

APPROACH	
<b>At Approximately 15 Nm from touchdown</b>	
FMGS : APPROACH PHASE	ACTIVATE
ENG START	NORM or IGN
APPR	PRESS
AT GREEN DOT	FLAPS 1
AT "S" SPEED	FLAPS 2
WHEN FLAPS 2	LANDING GEAR DOWN
GND SPOILERS	ARMED
LIGHTS : RWY TURN	ON
LIGHTS : NOSE	T.O
WHEN L/G DOWN & BELOW VFE	FLAPS 3
WHEN FLAPS 3 & BELOW VFE	FLAPS FULL
MISSED APPROACH ALT	SET

LANDING	
<b>AT 20 FT</b>	
FLARE	PERFORM
THRUST LEVERS	IDLE
<b>AT TOUCHDOWN</b>	
REVERSE	AS REQUIRED
BRAKES	AS REQUIRED
<b>AT 70 KT</b>	
REVERSE	IDLE
<b>AT TAXI SPEED</b>	
REVERSE	STOW
<b>BEFORE 20 KT</b>	
AUTO / BRK	DISENGAGE

AFTER LANDING	
WEATHER RADAR	OFF
WINDEAR	OFF
GND SPOILERS	DISARMED
FLAPS	FLAPS 0
TCAS	STBY
LIGHTS : STROBE	OFF
LIGHTS : LAND	OFF
LIGHTS : NOSE	TAXI
APU : MASTER SW	ON
APU BLEED	ON

PARKING	
PARK BRAKE	ON
ANTI ICE	OFF
ENG MASTER 1 & 2	OFF
ATC	STBY
LIGHTS : BEACON	OFF
LIGHTS : RWY TURN	OFF
LIGHTS : NOSE	OFF
SIGNS : SEAT BELTS	OFF
FUEL : L1, L2, R2 & R2	OFF

SECURING THE AIRPLANE	
ADR1, 2 & 3	OFF
APU BLEED	OFF
APU : MASTER SW	OFF
LIGHTS : NAV & LOGO	OFF
SIGNS : NO SMOKING	OFF
SIGNS : EMER EXIT LT	OFF
EXTERNAL POWER	AS REQUIRED
BAT 1 & 2	OFF
APU BAT	OFF

	OVERHEAD PANEL
	PEDESTAL
	MAIN PANEL
	FMS